
SHOULDER CHEST PRESS


FWX8100




Exploded View and Parts List

ITEM NO.	DESCRIPTION	QTY	ITEM NO.	DESCRIPTION	QTY
1	Base Frame	1	35	PlugPT60*120	4
2	Seat Support	1	36	Spacer	4
3	Right Upright Frame	1	37	Plugф48	6
4	left Upright Frame	1	38	PlugRT50*100	1
5	Right Arm Frame	1	39	Aluminium Cap	2
6	Left Arm Frame	1	40	Aluminium Cap φ76	2
7	Cross Bar	1	41	Aluminium Cap	4
8	Weight Horns	2	42	Ball Bearing	4
9	Adjustable Handle Assembly	1	43	Snap Spring	2
10	Weight Storage Horns	4	44	Nut M6*16.5	2
11	Counterweights	2	45	Button Head Cap Screw 3/8"-16*38	1
12	Arm Pivot Axle	2	46	Flat Head Cap Screw M12*35	2
13	Seat Support	1	47	Flat Head Cap Screw M12*30	4
14	Pivot	2	48	Socket Head Cap Screw M12*30	16
15	Handle Pivot Shaft	1	49	Socket Head Cap Screw M10*30	4
16	Middle Pivot Shaft	1	50	Socket Head Cap Screw M10*25	4
17	Torsion Spring	1	51	Socket Head Cap Screw M10*20	2
18	Gas Spring Assembly	1	52	Button Head Cap Screw M8*70	2
19	Seat Pad	1	53	Flat Head Cap Screw M8*20	4
20	Back Pad	1	54	Socket Set Screw M8*6	4
21	Bumper	1	55	Button Head Cap Screw M6*25	2
22	Plugф25	2	56	Flat Head Cap Screw M6*30	2
23	Grip	2	57	Flat Head Cap Screw M6*16	2
24	Rollers	3	58	Phillip Screw M4*10	2
25	Inner Slide	1	59	Phillip Screw M5*60	8
26	Outer Slide	1	60	Flat Washer	16
27	Bumper	2	61	Flat Washer ф11*ф20*2	10
28	Rubber Foot	3	62	Spring Washer ϕ 10	2
29	Handle Upper Cover	1	63	Flat Washer φ9*φ16*1.6	2
30	Handle Bottom Cover	1	64	Nylon Lock Nut M8	4
31	Safty Cover	2	65	Split damping ring φ15	4
32	Outer Safty Cover Assembly	2	66	Split damping ring φ12	2
33	Adjust Foot	1	67	Nut M5	8
34	Inner Bumper	2			


Exploded View and Parts List



Measurement Guide




ITEM NO.	DESCRIPTION	QTY
1	Base Frame	1
2	Seat Support	1
3	Right Upright Frame	1
4	left Upright Frame	1
48	Socket Head Cap Screw M12*30	12
60	Flat Washer φ13*φ24*1.5	12




ITEM NO.	DESCRIPTION	QTY
2	Seat Support	1
9	Adjustable Handle Assembly	1
13	Seat Support	1
14	Pivot	2
15	Handle Pivot Shaft	1
16	Middle Pivot Shaft	1
17	Torsion Spring	1
18	Gas Spring Assembly	1
25	Inner Slide	1
26	Outer Slide	1
45	Button Head Cap Screw 3/8"-16*38	1
51	Socket Head Cap Screw M10*20	2
52	Button Head Cap Screw M8*70	2


61	Flat Washer ϕ 11* ϕ 20*2	2
62	Spring Washer φ10	2
63	Flat Washer $\phi9*\phi16*1.6$	2
64	Nylon Lock Nut M8	4
65	Split damping ring φ15	4
66	Split damping ring φ12	2



ITEM NO.	DESCRIPTION	QTY
5	Right Arm Frame	1
6	Left Arm Frame	1
8	Weight Horns	2
32	Outer Safty Cover Assembly	2
41	Aluminium Cap	4
46	Flat Head Cap Screw M12*35	2
47	Flat Head Cap Screw M12*30	4
54	Socket Set Screw M8*6	4



ITEM NO.	DESCRIPTION	QTY
2	Seat Support	1
4	left Upright Frame	1
10	Weight Storage Horns	4
19	Seat Pad	1
20	Back Pad	1
22	Plugф25	2
48	Socket Head Cap Screw M12*30	4
49	Socket Head Cap Screw M10*30	4
60	Flat Washer \$13*\$24*1.5	4
61	Flat Washer ϕ 11* ϕ 20*2	4



General Maintenance Information

Links, Pull-Pins, Snap Hooks, Swivels, Weight Stack Pins:

- * Check all pieces for signs of visible wear or damage.
- * Check springs in snap hooks and pull-pins for proper tension and alignment.
- * If the spring sticks or has lost its rigidity, replace it immediately.

Upholstery:

- * To ensure prolonged upholstery life and proper hygiene, all upholstered pads should be wiped down with a damp cloth after every workout.
- * Periodically take the time to use a mild soap or an approved vinyl upholstery cleaner to deter the onset of cracking or drying. Avoid using any abrasive cleaners or cleaners not intended for use on vinyl.
- * Replace ripped or warn upholstery immediately.
- * Keep sharp or pointed objects clear of all upholstery.

Decals:

* Inspect and familiarize yourself with any safety warnings or other user information posted on each decal.

Nuts and Bolts:

- * Inspect all nuts and bolts for any loosening and tighten if needed.
- * Go through a re-tightening sequence periodically to ensure that all hardware is tensioned proper.

Anti-Skid Surfaces:

* These surfaces are designed to supply secure footing and need to be replaced if they appear worn or become slippery.

Belts and Cables:

- * We uses only high quality belt, and mil-spec cables.
- * Visually inspect the belts and cables for fraying, cracking, peeling or discoloration.
- * While the machine is not in use, carefully run your fingers along the belt or cable to feel for thinning or bulging areas.
- * Replace belts and cables immediately at the first signs of damage or wear. Do not use equipment until belts or cables have been replaced.

Belt and Cable Tension:

- * Referring to the Owners Manual, when belts or cables are used check all bolts attachments to be sure they are properly attached.
- * Check slack in cables and re-adjust cable tension if needed.


Seat Sleeves, Guide Rods:

- * Wipe down adjusting tubes with a dust free rag before applying lubricant.
- * Lubricate seat sleeves and Guide Rods with a Silicon or Teflon based lubricant spray.

Linear Bearings:

* Referring to the Owners Manual carefully disassemble the bearing from its housing and place a finger full of light grease (lithium, super lube, etc.) into the inside of the bearing. Using your finger, press the grease into the ball-bearings and their tracks. repeat until the ball-bearing tracks are full of grease. Insert the shaft back into the bearing and wipe off excess grease.

PLEASE KEEP THIS FOR YOUR RECORDS



Garlando

GARLANDO SPA
Via Regione Piemonte, 32 - Zona Industriale D1
15068 - Pozzolo Formigaro (AL) - Italy
contact@toorxprofessional.it
www.toorxprofessional.it